
Cleaning Reminder Timer instructions



Part functions: (See figure A)

Cleaning Reminder Timer Key

- Left Ctrl key
- **Cleaning Reminder Light**

Instructions:

- The cleaning reminder will allow you to program a blinking light (3) at timed intervals, to remind you that cleaning of the keyboard is desired.
- Hold down the Left Ctrl key (2).
- · Select from the interval options (See figure B) the desired cleaning reminder frequency: Press the Cleaning Reminder Timer key (1) as often as needed for desired interval.
- After cleaning, press Cleaning Reminder Timer Key (1) once to stop the blinking LED and reset the timer to the last setting.
- · To deactivate the cleaning reminder timer: while pressing and holding the Left Ctrl key (2), press and hold the Cleaning Reminder Timer Key (1) for two seconds.

(B` 12 н х24н

MAN & MACHINE

Note: The best practice for cleaning and disinfecting our keyboards and mice, including the cleaning frequency and method, will depend on the specific use and conditions in your hospital or clinical establishment. Your Infection Control Team can give you specific guidance on which cleaning protocols should be established in your facility. In general terms, we recommend treating our products as you would treat any other high frequency touch surface in the same room.

The Windows logo is a trademark or registered trademark of Microsoft Corporation in the United States and/or other countries.

USA. info@mmimd.com +13013414900

Europe: info@mmieu.com +31 (0) 23 5450185 IIK· info@mmieu.com +44 (0) 1937 830680



Copyright Man & Machine, Inc. 2017





ww.man-machine.com